

WEB Configuration Commands




Table of Contents

| | |
|---|-------------|
| WEB Configuration Commands | 錯誤! 尚未定義書籤。 |
| Chapter 1 HTTP Configuration Commands | 1 |
| 1.1 ip http port | 1 |
| 1.2 ip http secure-port | 1 |
| 1.3 ip http server | 2 |
| 1.4 ip http http-access enable | 2 |
| 1.5 ip http ssl-access enable | 2 |
| 1.6 ip http username | 2 |

Chapter 1 HTTP Configuration Commands

1.1 ip http port

Syntax

`ip http port { portNumber }`

It is used to set the HTTP port.

`no ip http port`

It is used to resume the HTTP port to be the default port 80.

Parameter

| Parameter | Description |
|-------------------|---|
| <i>portNumber</i> | Means the HTTP port's valid range is from 1 to 65535. |

Default

80

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the HTTP port to 1234.

```
Switch(config)#ip http port 1234
```

1.2 ip http secure-port

Syntax

`ip http secure-port { portNumber }` It is used to set the HTTPS port.

`no ip http secure-port`

It is used to resume the HTTPS port to be the default port 443.

Parameter

| Parameter | Description |
|-------------------|--|
| <i>portNumber</i> | Means the HTTPS port's valid range is from 1 to 65535. |

Default

443

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the HTTPS port to 1234.

```
Switch(config)# ip http secure-port 1234
```

1.3 ip http server

Syntax

```
[no] ip http server
```

It is used to enable the HTTP service.

Usage Guidelines

This command is configured in global configuration mode.

Example

It is used to enable the HTTP service.

```
Switch(config)# ip http server
```

1.4 ip http http-access enable

Syntax

```
[no] ip http http-access enable
```

It is used to set the HTTP access mode.

Usage Guidelines

This command is set in global configuration mode and used to access the website, which starts with <http://>.

Example

The following example shows how to set the HTTP access mode.

```
Switch(config)# ip http http-access enable
```

1.5 ip http ssl-access enable

Syntax

```
[no] ip http ssl-access enable
```

It is used to set the HTTPS access mode.

Usage Guidelines

This command is set in global configuration mode and used to access the website, which starts with <http://>.

Example

The following example shows how to set the HTTPS access mode.

```
Switch(config)# ip http ssl-access enable
```

1.6 ip http username

Syntax

```
ip http username{ username } password { password}
```

To set HTTP login username and password, run the above command.

```
no ip http username
```

To delete HTTP user configuration, run the above command.

Parameter

| Parameter | Description |
|-----------------|-------------------------|
| <i>username</i> | Username for HTTP login |
| <i>password</i> | Password for HTTP login |

Default

None

Usage Guidelines

This command is set in global configuration mode

Example

The following example shows how to set the username/password for http login to admin/admin:

```
Switch(config)#ip http username admin password admin
```