


If PoE still malfunction, and info show POE firmware version is 000-000.
Pls update the firmware v6.54.3584, and reload default and copy running-config startup-config.



The screenshot shows the 'Power Over Ethernet Configuration' page. At the top, there are radio buttons for 'Reserved Power determined by': 'Class' (unchecked), 'Allocation' (checked), and 'LLDP-Med' (unchecked). Below that, 'Power Management Mode' has 'Actual Consumption' (checked) and 'Reserved Power' (unchecked). Under 'Capacitor Detection', there is an unchecked checkbox. In the 'PoE Power Supply Configuration' section, 'PoE Firmware Version' is set to '000-000' and is highlighted with a red border. 'Primary Power Supply [W]' is set to '185'. The 'PoE Port Configuration' table has one row with an empty port number. At the bottom are 'Apply' and 'Reset' buttons.

Port	PoE Mode	PoE Schedule	Priority	Maximum Power [W]
*				