



LevelOne

GSW-2440

**24-Port Gigabit
Web Smart Switch**

User Manual

Version 1.0-0604

FCC Certifications



This Equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.

CE Mark Warning



This equipment complies with the requirements relating to electromagnetic compatibility, EN 55022 class A for ITE, the essential protection requirement of Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

Company has an on-going policy of upgrading its products and it may be possible that information in this document is not up-to-date. Please check with your local distributors for the latest information. No part of this document can be copied or reproduced in any form without written consent from the company.

Trademarks:

All trade names and trademarks are the properties of their respective companies.

Copyright © 2006. Digital Data Communications, Inc. All Rights Reserved.



Table of Contents

UNPACKING INFORMATION	5
INTRODUCTION	5
GENERAL DESCRIPTION	5
KEY FEATURES	5
THE FRONT PANEL	6
THE REAR PANEL	7
INSTALLATION	8
DESKTOP INSTALLATION	8
RACK-MOUNT INSTALLATION	8
INSTALLING NETWORK CABLES	9
NETWORK APPLICATION	9
FUNCTIONAL DESCRIPTION.....	10
JUMBO FRAME.....	10
FLOW CONTROL AND BACK PRESSURE	10
MIRROR.....	10
VLAN.....	10
TRUNK (AGGREGATION)	10
QUALITY OF SERVICE (QoS)	10
SNMP	10
MANAGEMENT GUIDE	11
ACCESS THE SWITCH.....	11
HOMEPAGE.....	12
SYSTEM.....	13
PORT	14

VLAN.....	15
PVID	16
AGGREGATION/ TRUNK CONFIGURATION	17
QUALITY OF SERVICE.....	18
MIRROR.....	22
RATE LIMIT	23
SNMP	24
DISCOVERY	25
STATISTICS OVERVIEW	26
DETAILED STATISTICS.....	26
WARM RESTART	27
FACTORY DEFAULT.....	27
SMART BOOT	27
SOFTWARE UPLOAD.....	28
PRODUCT SPECIFICATIONS	29

Unpacking Information

Thank you for purchasing **GSW-2440 Gigabit Web Smart Switch**. Before you start, please verify that your package contains the following items:

1. **One GSW-2440 Web Smart Switch**
2. **One AC power cord**
3. **Rack-mount brackets**
4. **Stackable kit**
5. **Manual CD**

Introduction

General Description

Easily boosting your networking throughput, LevelOne GSW-2440 provides you 24 10/100/1000Mbps gigabit ports that lead you to a real gigabit connection. Users are now able to transfer high bandwidth-demanded files faster and get a real efficiency improvement with the user-friendly web-based management interface.


The management functionalities provide efficient network usage. VLAN reduces the collisions from widely broadcasting. Port aggregation enlarges the bandwidth of backbone connection. QoS is supported to secure the bandwidth for some bandwidth-demanded applications including VoIP or videoconference. The 802.3x and backpressure flow control mechanisms are also supported to ensure the correctness of data transmitting.

Key Features

- 24 fixed 10/100/1000Mbps gigabit ethernet ports for easy network connecting application.
- Provide auto-discovery function for easy network management.
- Provide 8K MAC address entries and 24 groups VLAN table
- Support port mirror.
- Support up to 8 ports and 12 groups port aggregation.
- Support QoS for better communication quality.
- Support full duplex flow control and half duplex back pressure
- Store-and-forward forwarding scheme
- Error packet filtering
- Support Jumbo frames 9K bytes
- Supports 500K bytes buffer memory
- Support web-based management interface.
- FCC Class A, CE, Meet RoHS

The Front Panel

The front panel consists of LED indicators. Please refer to the following paragraph for information.



LEDs Definition

System LED

The switch provides a power LED for the device.

LED	Status	Operation
Power	Steady Green	The switch is powered on
	Off	The switch is powered off


Port LEDs

The switch provides one “1000M” LED and one “10/100M” LED for each port.

LED	Status	Operation
1000M	Green	The port is connected at 1000 Mbps
	Blinking Green	A valid link is established, and there is data transmitting/receiving.
	Off	No valid link on this port or the Port is connected at 10/100 Mbps
10/100M	Steady Green	A valid link is established, and there is no data transmitting/receiving.
	Blinking Green	A valid link is established, and there is data transmitting/receiving.
	Off	No valid link on this port or the port is connected at 1000 Mbps

The Rear Panel

The rear panel of the switch:



Port Operation

The auto-negotiation feature allows those ports running at one of the following operation modes:

Media	Speed	Duplex Mode
10/100/1000Mbps(copper)	10Mbps	Full Duplex
		Half Duplex
	100Mbps	Full Duplex
		Half Duplex
	1000Mbps	Full Duplex
		Full Duplex

Reset Button

You can use this button to reset the switch or restore factory default settings. To reset the switch, press the button once.

To restore factory default settings, press and hold the button for three seconds.

Power Receptacle

To be compatible with the electric service standards around the world, the switch is designed to afford the power supply in the range from 100 to 240VAC, 50/60Hz. Please make sure that your outlet standard to be within this range.

To power on the switch, please plug the female end of the power cord firmly into the receptacle of the switch and the other end into an electric service outlet. After the power cord installation, please check if the power LED is lit for a normal power status.

Installation

This switch can be placed on your desktop directly, or mounted in a rack. Please refer to the instructions for installation.

Before installing the switch, we recommend:

1. The switch is placed with appropriate ventilation environment. A minimum 25mm space around the unit is recommended.
2. The switch and the relevant components are away from sources of electrical noise such as radios, transmitters and broadband amplifiers.
3. The switch is away from environments beyond recommend moisture.

Desktop Installation

1. Install the switch on a level surface that can support the weight of the unit and the relevant components.
2. Plug the switch with the female end of the provided power cord and plug the male end to the power outlet.

Rack-mount Installation

The switch may be standalone, or mounted in a rack. Rack mounting facilitate to an orderly installation when you are going to install series of networking devices.

Procedures to rack-mount the switch:


1. Disconnect all the cables from the switch before continuing.
2. Place the unit the right way up on a hard, flat surface with the front facing you.
3. Locate a mounting bracket over the mounting holes on one side of the unit.
4. Insert the screws and fully tighten with a suitable screwdriver.
5. Repeat the two previous steps for the other side of the unit.
6. Insert the unit into the rack and secure with suitable screws (optional).
7. Reconnect all the cables.

Installing Network Cables

1. **Crossover or straight-through cable:** All the ports on the switch support auto-MDI/MDI-X functionality. Both straight-through or crossover cables can be used as the media to connect the switch with PCs as well as other devices like switches, hubs or router.
2. **Category 3,4,5 or 5eUTP/STP cable:** To make a valid connection and obtain the optimal performance. An appropriate cable that corresponds to different transmitting/receiving speed is required. To choose a suitable cable, please refer to the following table.

Media	Speed	Wiring
10/100/1000Mbps copper	10Mbps	Category 3,4,5 UTP/STP
	100Mbps	Category 5 UTP/STP
	1000Mbps	Category 5,5e UTP/STP

Network Application



Functional Description

Jumbo Frame

With Jumbo Frame supported, it is allowed for the switch to transport identical data in fewer frames. Hence helps to ensure fewer overheads, shorten processing time, and reduce interrupts.

Note: To enable Jumbo Frame, Flow Control should be enabled in advance.

Flow Control and Back Pressure

Flow Control and Back Pressure both contributes for lower and higher speed devices to communicate to each other hence ensures the correctness of data transmitting. The 802.3x Flow Control and Back Pressure mechanisms work respectively for full and half duplex modes. Flow Control can be enabled or disabled on a per-port basis.

Mirror

The Mirror function provides network administrator to monitor the traffic. By forwarding a copy of the packets that received or transferred by the monitored port, the sniffer port received all the packets and hence is able to monitor the traffic of the specified port.

VLAN

With VLAN supported, the network can be segmented in groups to reduce the collisions from widely broadcasting. The device supports both port-based VLAN and 802.1Q tag-based VLAN. Port-based VLAN classifies incoming packets to VLANs according to their ingress port. The 802.1Q based VLAN add a tag to the header of the packet to classify their VLANs.

Trunk (Aggregation)

The Trunk functionality integrates several ports to enlarge the bandwidth that helps to boost the backbone connectivity. The switch allows the Maximum 12 group and 8 members for each group.

Quality of Service (QoS)

The QoS service classifies packets into different precedence. The packets are transmitted and received by their classified priorities. This mechanism helps high bandwidth demanded applications such as VoIP to get an unobstructed connection.

SNMP

This device is SNMP(Simple Network Management Protocol)-management supported. This allows this product to be monitored or inspected by a SNMP management station.

Management guide

Access the Switch


This section instructs you how to enter and proceed the advanced management capability, which can be accessed by internet browser over the network.

To access the web-based management interface, you should configure the management station with an IP address and subnet mask that compatible to your switch.


The factory default value of the switch:

IP : 192.168.1.1
Subnet Mask : 255.255.255.0
Default Gateway : 192.168.1.254

1. Running your Web Browser and enter the IP address "192.168.1.1" in the Address field.



2. Key in the user name and password to pass the authentication. The factory default value of Username and Password is "admin".

A screenshot of a login page with a dark blue background. At the top, the text "Please enter password to login" is displayed in white. Below this text are two input fields: "Username:" with the value "admin" and "Password:" with the value "*****". At the bottom of the form is an "Apply" button.

Homepage

After authentication procedure, the “**SYSTEM Configuration**” page shows up as the Homepage. You may click the hyperlinks on the left side of each page to get access to each management functions.

level one

LEVELONE GSW-2440
24-PORT GIGABIT WEB SMART SWITCH

Configuration

- System
- Port
- VLAN
- Aggregation
- Quality of Service
- Mirror
- Rate Limit
- SNMP
- Discovery

Monitoring

- Statistics Overview
- Detailed Statistics

Maintenance

- Restart
- Factory Default
- Smart Boot
- Software Upload

System Configuration

MAC Address	00-11-6b-00-00-03
SW Version	v1.3
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Gateway	192.168.1.254
Management VLAN	1
User name	admin
Password	*****
Systemname	GSW-2440

Apply Refresh

System

The “**System**” window provides the switch information and allows users to configure the switch properties.

The screenshot shows a web-based configuration interface titled "System Configuration". It contains a table of configuration fields with labels on the left and input areas on the right. The fields are: MAC Address (00-11-6b-f0-00-03), S/W Version (v1.3), IP Address (192.168.1.1), Subnet Mask (255.255.255.0), Gateway (192.168.1.254), Management VLAN (1), User name (admin), Password (masked with asterisks), and Systemname (GSW-2440). Below the table are two buttons: "Apply" and "Refresh".

System Configuration	
MAC Address	00-11-6b-f0-00-03
S/W Version	v1.3
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Gateway	192.168.1.254
Management VLAN	1
User name	admin
Password	*****
Systemname	GSW-2440

Apply Refresh

Items	Functions
MAC Address:	The MAC address of this device..
S/W Version:	The software version of this device.
IP Address:	Setup the IP address of the switch
Subnet Mask:	Setup the Subnet Mask of the switch
Gateway:	Setup the Gateway of the switch
Management VLAN:	The VLAN group that is allowed to access the WEB-based management interface.
User Name:	The Login name. (Default: admin)
Password:	The Login password. (Default: admin)
System Name:	The name of the device.

To save the configuration of the system, click “**Apply**” to save

Note:

After applying a new IP address, a new login page will be started automatically. Please login again to proceed to other configurations.

Port

This “**Port Configuration**” page shows the link status of each port and allows users to configure speed, flow control and Max frame size for each port.

Port Configuration				
Port	Link	Mode	Flow Control	MaxFrame
1	Down	Auto Speed	<input type="checkbox"/>	1518
2	Down	Auto Speed	<input type="checkbox"/>	1518
3	Down	Auto Speed	<input type="checkbox"/>	1518
4	Down	Auto Speed	<input type="checkbox"/>	1518
5	Down	Auto Speed	<input type="checkbox"/>	1518
6	Down	Auto Speed	<input type="checkbox"/>	1518
7	Down	Auto Speed	<input type="checkbox"/>	1518
8	Down	Auto Speed	<input type="checkbox"/>	1518
9	1000FDX	Auto Speed	<input type="checkbox"/>	1518
10	Down	Auto Speed	<input type="checkbox"/>	1518
11	Down	Auto Speed	<input type="checkbox"/>	1518
12	Down	Auto Speed	<input type="checkbox"/>	1518
13	Down	Auto Speed	<input type="checkbox"/>	1518
14	Down	Auto Speed	<input type="checkbox"/>	1518
15	Down	Auto Speed	<input type="checkbox"/>	1518
16	Down	Auto Speed	<input type="checkbox"/>	1518
17	Down	Auto Speed	<input type="checkbox"/>	1518
18	Down	Auto Speed	<input type="checkbox"/>	1518
19	Down	Auto Speed	<input type="checkbox"/>	1518
20	Down	Auto Speed	<input type="checkbox"/>	1518
21	Down	Auto Speed	<input type="checkbox"/>	1518
22	Down	Auto Speed	<input type="checkbox"/>	1518
23	Down	Auto Speed	<input type="checkbox"/>	1518
24	Down	Auto Speed	<input type="checkbox"/>	1518

Apply Refresh

Items	Functions
Link	Shows the link status of each port. The column lights green with the link speed while there is valid connection on this port.
Mode	Select a speed for this port. “ Auto Speed ” enables auto-negotiation. “ Disable ” stop the port from functioning.
Flow Control	Mark the checkbox to enable the FDX Flow control, or unmark to disable.
Max Frame length	To adjust the size of Jumbo Frame. The length is 1518 bytes. The Maximum value can be up to 9600 bytes.

To save the configuration of the system, click “**Apply**” to save. You can also click the “**Refresh**” button to see the latest status of each port.

VLAN

VLAN divides the network members into groups to reduce packets collisions and improve the network efficiency. The switch supports 802.1Q tag-based VLAN. Please follow the instructions to configure.

- To add new VLAN groups,
 1. Fill in a VLAN id from 2 to 4094 in the “**VLAN\Port**” column.
 2. Select the ports for each VLAN groups.
 3. Click the “**Apply**” button to execute.
- To delete a VLAN group
 1. Clear the members of this VLAN group by clicking those marked checkboxes.
 2. Clear the VLAN id of the VLAN you want to remove in the “**VLAN\Port**” column. (Don't type N/A. Just leave it blank)
 3. Click the “**Apply**” button to execute.

[illegible]

Note:

1. When a port is configured to a specific VLAN group, a PVID that corresponding to the VLAN id will be assigned automatically to this port. (Ex, when you make port 3 of a VLAN with VLAN id "2", the PVID "2" will be assigned automatically to port 3)
2. Settings in VLAN, Port aggregation, and Mirror are correlative. Please make sure that the setting won't influence each other.

PVID

When the VLAN-enabled switch receives a tagged packet, the packet will be sent to the port's default VLAN according to the PVID (port VLAN ID) of the receiving port.

Items	Functions																				
Port	Port Number 1~24																				
Egress	<p>Select “tagged” in the drop list to enable the PVID checking and tag inserting of one port, and select “untagged” to cancel.</p> <p>For example, if an Egress-tagged port receives an untagged frame, it will be transmitted as a PVID tagged frame. For the detail tagging status, please refer to the following table.</p> <table><tr><th colspan="2">Untagged</th><th colspan="2">Tagged</th></tr><tr><th>Packet Frames In</th><th>Packet Frames Out</th><th>Packet Frames In</th><th>Packet Frames Out</th></tr><tr><td>Untagged</td><td>Untagged</td><td>Untagged</td><td>Tagged (PVID)</td></tr><tr><td>Tagged</td><td>Untagged</td><td>Tagged (VID)</td><td>Tagged (VID)</td></tr><tr><td>Pri-tagged</td><td>Untagged</td><td>Pri-tagged</td><td>Tagged (PVID)</td></tr></table>	Untagged		Tagged		Packet Frames In	Packet Frames Out	Packet Frames In	Packet Frames Out	Untagged	Untagged	Untagged	Tagged (PVID)	Tagged	Untagged	Tagged (VID)	Tagged (VID)	Pri-tagged	Untagged	Pri-tagged	Tagged (PVID)
Untagged		Tagged																			
Packet Frames In	Packet Frames Out	Packet Frames In	Packet Frames Out																		
Untagged	Untagged	Untagged	Tagged (PVID)																		
Tagged	Untagged	Tagged (VID)	Tagged (VID)																		
Pri-tagged	Untagged	Pri-tagged	Tagged (PVID)																		
PVID	Port VLAN ID(1~4094)																				
Only tagged	<p>Enable: block all un-tagged packets from accessing this port.</p> <p>Disable: All packets are allowed to access this port.</p>																				

PVID Configuration			
Port	Egress	PVID	Only tagged
1	Untagged ▼	1	Disable ▼
2	Untagged ▼	1	Disable ▼
3	Untagged ▼	1	Disable ▼
4	Untagged ▼	1	Disable ▼
5	Untagged ▼	1	Disable ▼
6	Untagged ▼	1	Disable ▼
7	Untagged ▼	1	Disable ▼
8	Untagged ▼	1	Disable ▼
9	Untagged ▼	1	Disable ▼
10	Untagged ▼	1	Disable ▼
11	Untagged ▼	1	Disable ▼
12	Untagged ▼	1	Disable ▼
13	Untagged ▼	1	Disable ▼
14	Untagged ▼	1	Disable ▼
15	Untagged ▼	1	Disable ▼
16	Untagged ▼	1	Disable ▼
17	Untagged ▼	1	Disable ▼
18	Untagged ▼	1	Disable ▼
19	Untagged ▼	1	Disable ▼
20	Untagged ▼	1	Disable ▼
21	Untagged ▼	1	Disable ▼
22	Untagged ▼	1	Disable ▼
23	Untagged ▼	1	Disable ▼
24	Untagged ▼	1	Disable ▼

Apply Refresh

Aggregation/ Trunk Configuration

To set up the port trunk groups, put the ports number into the same aggregation group. There are twelve groups to choose. Don't forget to click the “**Apply**” to save the setting.

There are three aggregation modes for you to setup, SMAC (Source MAC), DMAC (Destination MAC), and XOR. SMAC mode selects the path of packets according to source MAC while DMAC mode selects path according to destination MAC. XOR mode calculates the result of DMAC and SMAC mode to decide the path of packets.

Aggregation/Trunking Configuration

Mode	xor																							
Group\Port	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Normal	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Group 1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 5	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 6	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 7	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 8	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 9	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 10	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 11	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Group 12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Quality of Service

QoS enhances the communication quality by giving different precedence to classified packets. This switch provides port-based, tag-based and DSCP QoS modes:

QoS Configuration

Port	Mode
1	Port
2	Port
3	Port
4	Port
5	Port
6	Port
7	Port
8	Port
9	Port
10	Port
11	Port
12	Port
13	Port
14	Port
15	Port
16	Port
17	Port
18	Port
19	Port
20	Port
21	Port
22	Port
23	Port
24	Port

Port priority

Tag priority

DSCP priority

Apply

Refresh

Port-based mode QoS:

The port-based QoS allows users to configure certain ports as high or low priority. To give priority level for each port:

- 1. Select **“Port”** in the **“Mode”** column for those ports that are going to perform port-based QoS. Click the **“Apply”** button.
- 2. Click the **“Port priority”** button. The **“Port Priority Setting”** page shows up.
- 3. Click on the drop list to specify priority levels.
- 4. Click **“Apply”** to execute.

Port priority setting

1	Low
2	Low
3	Low
4	Low
5	Low
6	Low
7	Low
8	Low
9	Low
10	Low
11	Low
12	Low
13	Low
14	Low
15	Low
16	Low
17	Low
18	Low
19	Low
20	Low
21	Low
22	Low
23	Low
24	Low

Apply Refresh

Tag based QoS:

The tag-based QoS decides packet priority according to the tags that adding on the packets.

To configure tag-based QoS configuration:

1. Select **"Tagged"** in the **"Mode"** column for those ports that are going to perform tag-based QoS. Click the **"Apply"** button.
2. Click the **"Tag priority"** button. The **"Tag Priority Setting"** page shows up.
3. Select the port that you are going to configure from the drop list.
4. Give the priorities as high or low for each Priority Tag types.
5. Click the **"Apply"** button again to execute your configuration.

Tag priority setting

Port	Bit 0	Bit 1	Bit 2	Priority
Port1 ▾	0	0	0	Low ▾
	0	0	1	Low ▾
	0	1	0	Low ▾
	0	1	1	Low ▾
	1	0	0	Low ▾
	1	0	1	Low ▾
	1	1	0	Low ▾
	1	1	1	Low ▾

DSCP mode QoS:

The DSCP mode QoS gives packet priority by the precedent types attaching on the incoming packets.

The types of precedence:

- 000 - Routine
- 001 - Priority
- 010 - Immediate
- 011 - Flash
- 100 - Flash Override
- 101 - CRITIC/ECP
- 110 - Internetwork Control
- 111 - Network Control

To configure DSCP Based QoS configuration:

1. Select **"DSCP"** in the **"Mode"** column for those ports that are going to perform DSCP-based QoS. Click the **"Apply"** button.
2. Click the **"DSCP priority"** button. The **"DSCP Priority Setting"** page shows up.
3. Give the priorities as high or low for each DSCP information types.
4. Click the **"Apply"** button again to execute your configuration.

DSCP priority setting

Bit 0	Bit 1	Bit 2	Priority
0	0	0	Low
0	0	1	Low
0	1	0	Low
0	1	1	Low
1	0	0	Low
1	0	1	Low
1	1	0	Low
1	1	1	Low

Apply Refresh

Mirror

The **Mirror** function copies all the packets that are received or transmitted by the source port to the destination port. It allows administrators to analyze and monitor the traffic of the monitored ports.

Mirror Configuration:

1. Select those ports that are going to be monitored by marking the checkboxes in “**Monitor Port**” column.
2. Click the drop list in “**Sniffer Port**” column. Select a port as the administration port for monitoring those source ports.
3. Click “**Apply**” to activate.

Mirror Configuration

Sniffer port

port1

Monitor port

<input type="checkbox"/> port1	<input type="checkbox"/> port2	<input type="checkbox"/> port3	<input type="checkbox"/> port4	<input type="checkbox"/> port5	<input type="checkbox"/> port6	<input type="checkbox"/> port7	<input type="checkbox"/> port8	<input type="checkbox"/> port9	<input type="checkbox"/> port10	<input type="checkbox"/> port11	<input type="checkbox"/> port12
<input type="checkbox"/> port13	<input type="checkbox"/> port14	<input type="checkbox"/> port15	<input type="checkbox"/> port16	<input type="checkbox"/> port17	<input type="checkbox"/> port18	<input type="checkbox"/> port19	<input type="checkbox"/> port20	<input type="checkbox"/> port21	<input type="checkbox"/> port22	<input type="checkbox"/> port23	<input type="checkbox"/> port24

Apply Refresh

Rate Limit

This “**Rate Limit**” page allows users to configure the rules for storm control. You may also limit the speed of incoming and outgoing frames for each port.

To perform storm control:

1. Click on each drop list to specify a speed for each frame type.
2. Click the “**Apply**” button to execute your configuration.

Storm Control	
Number of frames per second	
ICMP Rate	No Limit ▼
Broadcast Rate	No Limit ▼
Multicast Rate	No Limit ▼

To restrict the incoming and outgoing speed for each port:

1. Click the “**Ingress**” drop list to specify the speed of incoming frames for each port.
2. Click the “**Egress**” drop list to specify the speed of outgoing frames for each port.


Port	Ingress	Egress
1	No Limit ▼	No Limit ▼
2	No Limit ▼	No Limit ▼
3	No Limit ▼	No Limit ▼
4	No Limit ▼	No Limit ▼
5	No Limit ▼	No Limit ▼
6	No Limit ▼	No Limit ▼
7	No Limit ▼	No Limit ▼
8	No Limit ▼	No Limit ▼
9	No Limit ▼	No Limit ▼
10	No Limit ▼	No Limit ▼
11	No Limit ▼	No Limit ▼
12	No Limit ▼	No Limit ▼
13	No Limit ▼	No Limit ▼
14	No Limit ▼	No Limit ▼
15	No Limit ▼	No Limit ▼
16	No Limit ▼	No Limit ▼
17	No Limit ▼	No Limit ▼
18	No Limit ▼	No Limit ▼
19	No Limit ▼	No Limit ▼
20	No Limit ▼	No Limit ▼
21	No Limit ▼	No Limit ▼
22	No Limit ▼	No Limit ▼
23	No Limit ▼	No Limit ▼
24	No Limit ▼	No Limit ▼

Apply Refresh

SNMP

This device supports SNMP-management, which allows network administrators to monitor and configure this device with SNMP software. To allow this device to be managed via SNMP:

1. Select “enable” in the drop list.
2. Specify a trap IP. A trap IP is the destination port for sending trap information, which is usually the IP address of network administrators.
3. Fill in a name in the “Community Get” text box, which is the password for accessing MIB with read-only authority.
4. Fill in a name in the “Community Set” text box, which is the password for accessing MIB with read and write authority.



The image shows a web-based configuration interface for SNMP. It has a dark blue header with the title "SNMP Configuration" in white. Below the header is a form with four rows of configuration fields. The first row is "Mode" with a dropdown menu set to "Enable". The second row is "Trap IP" with a text box containing "0.0.0.0". The third row is "Community Get" with a text box containing "public". The fourth row is "Community Set" with a text box containing "private". At the bottom of the form are two buttons: "Apply" and "Refresh".

SNMP Configuration	
Mode	Enable
Trap IP	0.0.0.0
Community Get	public
Community Set	private

Apply Refresh


Discovery

After installing series of LevelOne gigabit web smart switches(GSW-0841/1641/2440), the discovery management tool helps users to search and get access to those switches within the LAN.

Note. The discovery tool lists the Maximum 16 devices respectively for auto and manual modes.

Auto Search

1. Click the “**Apply**” button to start.
2. The devices being found are listed below.
3. Click the IP address hyperlink to get access to the device.



Discovery

Auto Search

Manual Add

IP Address: Name:

Manual Add

Add

1. Enter the IP address & name in the text box
2. Click “**Add**” to add the new IP address on the table

Delete

1. Click the check box of the one you want to remove
2. Click “**Delete**” to remove.

Statistics Overview

The Statistics Overview is provided for users to see the general transmitting and receiving status of each port. You may click the “**Clear**” button to clean all statistics or click the “**Refresh**” button to renew the statistics.

Statistics Overview for all ports						
<div>Clear Refresh</div>						
Port	Tx Bytes	Tx Frames	Rx Bytes	Rx Frames	Tx Errors	Rx Errors
1	0	0	0	0	0	0
2	0	0	0	0	0	0
3	0	0	0	0	0	0
4	0	0	0	0	0	0
5	0	0	0	0	0	0
6	0	0	0	0	0	0
7	0	0	0	0	0	0
8	0	0	0	0	0	0
9	185927	407	622714	5074	0	0
10	0	0	0	0	0	0
11	0	0	0	0	0	0
12	0	0	0	0	0	0
13	0	0	0	0	0	0
14	0	0	0	0	0	0
15	0	0	0	0	0	0
16	0	0	0	0	0	0
17	0	0	0	0	0	0
18	0	0	0	0	0	0
19	0	0	0	0	0	0
20	0	0	0	0	0	0
21	0	0	0	0	0	0
22	0	0	0	0	0	0
23	0	0	0	0	0	0
24	0	0	0	0	0	0

Detailed Statistics

The Detailed Statistics is provided for users to see the detailed transmitting and receiving status of each port. Please click the hyperlinks above to select a port. You may also click the “**Clear**” button to clean all statistics or click the “**Refresh**” button to renew the statistics.

Statistics for Port 1						
<div>Clear Refresh</div>						
<div>Port 1 Port 2 Port 3 Port 4 Port 5 Port 6 Port 7 Port 8</div>						
<div>Port 9 Port 10 Port 11 Port 12 Port 13 Port 14 Port 15 Port 16</div>						
<div>Port 17 Port 18 Port 19 Port 20 Port 21 Port 22 Port 23 Port 24</div>						
Receive Total				Transmit Total		
Rx Packets		0		Tx Packets		0
Rx Octets		0		Tx Octets		0
Rx Broad- and Multicast		0		Tx Broad- and Multicast		0
Rx Error Packets		0		Tx Error Packets		0

Warm Restart

Restart:

To restart the system, click the “**Yes**” button. The system will restart and show the authentication window. Please fill in the username and password to continue.

Restart

Are you sure you want to perform a Restart?

Factory Default

Restore Factory Default:

To restore the factory default value, click the “**Yes**” button.

Note: The IP address of the device will also be configured as factory-default setting, which is 192.168.1.1.

Factory Default

Are you sure you want to perform a Factory Default?

Smart Boot

This Smart Boot page allows users to select the booting flash of the device.

“**Active image number**” shows the current flash for booting the device. To change the booting flash, click on your demanding flash in the “**Boot image number**” row and click the “**Apply**” button to execute.

Booting flash Configuration

Active image number:	Version 1.3
Boot image number:	<input checked="" type="radio"/> Auto detect <input type="radio"/> Version 1.3 <input type="radio"/> Version 1.2


Software Upload

This “**Software Upload**” page allows users to upgrade firmware for this switch.

To perform firmware upgrade:

1. Click the “**Browse**” button.
2. Locate the firmware file.
3. Click the “**Upload**” button to execute.

Note: This new firmware is going to be applied on the other flash that you select in “**Smart Boot**”, that is, the new firmware is going to be applied on the flash that is **NOT** chosen as the booting flash. Please ensure that you boot this device with correct flash before performing firmware upgrade.



Product Specifications

Standard	IEEE802.3 10BASE-T IEEE802.3u 100BASE-TX IEEE802.3x full-duplex operation and flow control IEEE802.3ab 1000BASE-T IEEE802.1Q VLAN interoperability IEEE802.1p Priority Operation
Interface	24* 10/100/1000Mbps auto MDI/MDI-X RJ-45 switching ports 1 * Reset Button
Cable Connections	RJ-45 (10BASE-T): Category 3,4,5 UTP/STP RJ-45 (100BASE-TX): Category 5 UTP/STP RJ-45 (1000BASE-T): Category 5,5e or enhanced UTP/STP
Network Data Rate	10/100/1000Mbps Auto-negotiation
Transmission Mode	10/100Mbps Full-duplex, Half-duplex 1000Mbps Full-duplex
LED indications	System Power RJ-45 Port 1000M, 10/100M
Memory	8K MAC entries 500K Buffer Memory 9K Byte Jumbo Frame
Emission	FCC Class A, CE, RoHS
Operating Temperature	0 ⁰ ~ 40 ⁰ C (32 ⁰ ~ 104 ⁰ F)
Operating Humidity	10% - 90% (non-condensing)
Power Supply	Internal power supply 100-240V/ 50-60Hz universal input