

How to reset KVM-0831 / 1631?

Please flip over your KVM-0831/1631, you will see a rectangular hole.



You can use a paper clip to short circuit for about 10 seconds then the password will be reset to default "00000000".

