

## 1650; 1651 Function Settings

No	File Name	Contents
1	cb-meetmeloginpsw.wav	請輸入語音會議室密碼 Please input the conference room password
2	conf-onlyperson.wav	歡迎進入語音會議室，您是第一位用戶 Welcom to the conference room, you are the first attendant
3	conf-adminmenu.wav	使用靜音模式請按 1，鎖定當前語音會議室請按 2，踢出所有普通用戶請按 3，靜音所有普通用戶請按 4，解除普通用戶靜音模式請按 5，邀請好友請按 6 Press one for changing mute mode, press two for lock the meet. Press three for kicking out all normal users. Press four for mute all normal users,press five for unmute all normal users. Press six for invite new attendants
4	conf-kickall.wav	所有普通用戶已經被踢出 All normal users are kicked out now
5	conf-allmuted.wav	所有普通用戶已被靜音 All normal users are muted now
6	conf-allunmuted.wav	所有普通用戶靜音模式已被解除 All normal users are unmuted now
7	conf-invitesend.wav	邀請已送出，請稍候 The Invitation has been send out, A moment please.
8	conf-usermenu.wav	切換靜音模式，請按 1，獲得管理許可權，請按 2 To change mute mode press one. To get admin competence press two
9	fucn-fobiden.wav	該功能已被禁用 The functions has been disabled
10	cb-adminpsw.wav	請輸入管理員密碼 please input admin password
11	conf-admingotten.wav	您獲得了管理許可權 you have gotten admin competence.
12	cb-invitenum.wav	請輸入您要邀請的電話號碼 please input the number you want to invite
13	conf-kicked.gsm	對不起，您無權進入該語音會議室 Sorry, you don't have the right to enter the meet
14	conf-muted.wav	您設置了靜音模式，其他人將無法聽到您的聲音 You have changed into the mute mode, others will not hear what you say from now on
15	conf-unmuted.wav	靜音模式解除 You have canceled the mute mode
16	password-matcherror.wav	Sorry, the password is uncorrected, please try again.
17	conf-lockednow.wav	語音會議室已經被鎖定

		The meet have been locked, 語音會議室鎖定解除 You have unlocked the meet
18	conf-unlockednow.wav	
19	conf-errorenu.wav	無效的號碼 Wrong input
20	conf-locked.wav	您選擇的語音會議室已鎖定 The meet have been locked , please contact the administrator.
21	conf-noempty.wav	你選擇的語音會議室已滿 The meet have no room for you, please contact the administrator
22	wait_totalk.wav	您被管理員禁止說話 You have been muted by the administrator
23	can_talk.wav	您現在可以說話 You have been unmuted by the administrator

#### 1602 分機功能設置 Extensions Functions manag:

No	File Name	Contents
1	Pbxivr_menu.gsm	設置呼叫轉移請按 1，設置一號通請按 2，設置號碼綁定請按 3，回復正常模式請按 0，用戶密碼更新請按 4，放棄請掛機 Setting configuration: Press “1” for call transfer, Press “2” for call forward, Press “3” for number bonding, Press “0” for back to normal, Press “4” for password renewal, Hang up the cradle to abort the setting.
2	Pbxivr_setforwardme_menu.gsm	設置無條件呼叫轉移請按 1，設置遇忙呼叫轉移請按 2，設置無應答呼叫轉移請按 3 設置不線上呼叫轉移請按 4。 Press “1” for All Forward, Press “2” for Busy Forward, Press “3” for No Answer Forward, Press “4” for Unavailable Forward.
3	Cb_forwardestnum.gsm	請輸入無條件呼叫轉移的目的號碼，以 # 號結束 Please input All Forward Destination number and end up with “# (pound)” key.
4	Cb_Echo.gsm	您輸入的號碼是： Your input number is:
5	Cb_confirm.gsm	確認請按 1，重新輸入請按 2，放棄請按其他鍵 Press “1” for confirmation, Press “2” for re-keying the number, Press other key to abort the setting.
6	Forwardestnumsucces.gsm	您的所有來電都將被轉移到： All the incoming calls will be transferred to:
7	Cb_busydestnum.gsm	請輸入遇忙呼叫轉移的目的號碼，以 # 號結束 Press Busy Forward Destination number and end up by pound key
8	Cb_noanswerdest.gsm	請輸入無應答呼叫轉移的目的號碼，以 # 號結束

		Press No Answer Forward Destination number and end up by pound key
9	Cb_unavaildestnum.gsm	請輸入不線上呼叫轉移的目的號碼，以#號結束 Press Unavailable Forward Destination number and end up by pound key
10	pbx_confirm_delete.gsm	刪除已有的一號通請按1，保留已有的一號通請按2，放棄請按其他鍵 Press “1” to delete Call Forward number, Press “2” to keep existing Call forward number, Press other key to abort the setting.
11	cb_findme.gsm	請輸入一號通號碼，以#號結束 Press Forward Destination number and end up by pound key
12	cb_pri.gsm	請輸入此號碼的優先值，以#號結束 Press priority for this Forward Destination number and end up by pound key.
13	cb_findmewaitime.gsm	請輸入此號碼的等待時間，以秒為單位 Press waiting time period in second for call forwarding.
14	pbx_echo_inputime.gsm	你輸入的等待時間是 Waiting time period is:
15	pbx_continue_confirm.gsm	完成請按1，繼續請按其他鍵 Press “1” to complete the setting or other key to continue the setting
16	Confirm_bindme.gsm	刪除已有的綁定號碼請按1，保留已有的綁定號碼請按2，放棄請按其他鍵 Press “1” to delete existing bonding number, Press “2” to keep the existing bonding number. Press other key to abort the setting
17	Cb_bindmedestnum.gsm	請輸入綁定到此帳戶的號碼，以#號結束： Press the account number of the bonding and end up by pound key
18	Success.gsm	設置成功！ Setting completed.
19	Failed.gsm	設置失敗 Setting failed.
20	Telephonenumber.gsm	您的號碼是： Your number is:
21	pbx_pswchange_attention.gsm	請注意：如果您設置了新的密碼，請更新您自己相應終端的密碼，否則，您下次將不能在相應終端上使用該帳號 Please be noted to update the new password onto device setting as well or you shall not perform the device well
22	pbx_confirm_continue.gsm	繼續請按1，放棄請按其他鍵 Press “1” for continuing or other key to abort.
23	cb_newpswd.gsm	請輸入新密碼，以#號結束

		Press new password and end up with pound key.
24	cb_newpswdconfirm.gsm	請再次輸入新密碼。 Please re-enter the password
25	cb_newpswderror.gsm	您輸入的新密碼和確認密碼不相等！ Your new password is incorrect.
26	pbx_pswdsuccess.gsm	密碼修改成功，請及時更新您相應終端的密碼 Password update completed and please update the password on the device setting too.
27	1.gsm	1 one
28	2.gsm	2 two
29	3.gsm	3 three
30	4.gsm	4 four
31	5.gsm	5 five
32	6.gsm	6 six
33	7.gsm	7 seven
34	8.gsm	8 eight
35	9.gsm	9 nine
36	0.gsm	0 zero

### 1600 Calling queues management :

No	File Name	Contents
1	queue_welcome.gsm	這裏是呼叫 <b>順序</b> 管理中心，請輸入你要管理的順序的接入號碼，以#號結束： This is calling queue management administration. Please press the access number of the queue and end up with pound key.
2	queue_inputpass.gsm	請輸入該 <b>順序</b> 的密碼，以#號結束 Please key in the password and end up by pound key.
3	queue_pswerror.gsm	您輸入的接入號碼或密碼錯誤，請重新輸入 Password incorrect, please try again.
4	queue_option.gsm	加入該 <b>順序</b> ，請按 1，退出該 <b>順序</b> 請按 2 Prees “1” to join the queue, Press “2” to exit.
5	queue_regd.gsm	您已經加入該 <b>順序</b> You are in the queue now.

6	queue_unregd.gsm	您已經退出該 <b>順序</b> You has exit the queue.
7	cb_error.gsm	您的輸入錯誤 Wrong pass word.
8	queue_fail.gsm	<b>順序</b> 操作失敗 Queue operation failed

### 1601 Operator Function setting :

No	File Name	Contents
1	switchboard_welcome.gsm	這裏是 <b>總機</b> 設置管理，請輸入登入密碼： This is operator administration. Please key the access password:
2	switchboard_pswerror.gsm	您輸入的密碼有誤，請重新輸入 Incorrect password, please try again.
3	switchboard_option.gsm	設置本機為 <b>總機</b> ，請按 1，取消本機的 <b>總機</b> 設置，請按 2 Press “1” to set the device as operator, Press “2” to cancel the assignment.
4	Success.gsm	設置成功 Setting completed.
5	switchboard_regd.gsm	您已成為 <b>總機</b> You has been the operator device.
6	switchboard_unregd.gsm	您的 <b>總機</b> 設置已取消 The operator device has been deleted.

### 112 Autoattend or Other :

No	File Name	Contents
1	sippbx.gsm	您好，歡迎致電本公司，請 <b>直撥分機號碼</b> ，或按 0 由 <b>總機為您服務</b> Welcom to about company , Please dial exten the one or press 0 to the operator for help.
2	OUTFAILED.gsm	抱歉，您撥打的號碼暫時無法接通，轉 <b>總機</b> 諮詢請按 1 號健 Sorry, The exten the dial con't be connected, press “1” to the operator
3.	CONGESTION.gsm	抱歉,您撥打的用戶暫時無法接通,轉 <b>總機</b> 請按 1 號健，留言請撥 2 號健 Sorry, The exten the dial con't be connected, press “1” to the operator press “2” to leave the message.
4	NOANSWER.gsm	抱歉，您撥打的電話暫時無人接聽,轉 <b>總機</b> 請按 1 號健，留言請撥 2 號健 Sorry, No one answer the extension , press “1”to the operator press “2” to leave the message .
5	CHANUNAVAIL.gsm	抱歉，您撥打的用戶不線上,轉 <b>總機</b> 請按 1 號健，留言請

		撥 2 號健 Sorry , the exten the dial invalid all one, press "1" to the operator press "2" to leave the message.
6	BUSY.gsm	抱歉，您撥打的用戶正在通話中，轉總機請按 1 號健，留言請撥 2 號健 Sorry, the exten the dial is busy now , press "1" to the operator press "2" to leave the message.
7	transfer.gsm	轉接中，請稍候。 Please hold , I'll try this extension ...`
8	Wait.gsm	Please hold , I'll try this extension ...`

### 1603;1604 語音信箱查詢

No	File Name	Contents
154	vm-Cust1.gsm	文件夾 5 Folder 5
155	vm-Cust2.gsm	文件夾 6 Folder 6
156	vm-Cust3.gsm	文件夾 7 Folder 7
157	vm-Cust4.gsm	文件夾 8 Folder 8
158	vm-Cust5.gsm	文件夾 9 Folder 9
159	vm-and.gsm	和 And
160	vm-changeto.gsm	請選擇要進入的資料夾？ Change to which folder ?

No	File Name	Contents
161	vm-delete.gsm	刪除當前留言，請按 7。 Press "7" to delete this message.
162	vm-deleted.gsm	刪除留言成功。 Message deleted.
163	vm-extension.gsm	請輸入電話分機號碼 Extension
164	vm-Family.gsm	家人 Family
165	vm-first.gsm	第一條 Frist
166	vm-for.gsm	請輸入欲聽取的分機號碼 for
167	vm-Friends.gsm	朋友 Friends

168	vm-goodbye.gsm	再見 Goodbye
169	vm-helpexit.gsm	需要幫助請按*號鍵，退出請按#號鍵 Press “*” for help or pound for to exit.
170	vm-INBOX.gsm	新的 New
171	vm-incorrect-mailbox.gsm	登錄失敗。請重新登入 Login incorrect , Mailbox :
172	vm-incorrect.gsm	登錄失敗。 Login incorrect.
173	vm-instructions.gsm	收聽留言，請按 1；退出請按#號鍵 To looking hear messages press “1” now, you may quit voicemail at any time by press the pound key.
174	vm-intro.gsm	請在提示音後留言，留言結束請按#號鍵或掛機。 Please message after the tone , when done, hung up or press pound key.
175	vm-isonphone.gsm	正在通話中 It on the phone.
176	vm-isunavail.gsm	暫時無法接通 It unavailable .
177	vm-last.gsm	留言時長為 Last
178	vm-login.gsm	請輸入您要查詢的留言的號碼，以#號鍵結束 To me in the mail , mailbox :
179	vm-message.gsm	留言 message
180	vm-messages.gsm	留言 messages

No	File Name	Contents
181	vm-mismatch.gsm	兩次輸入的密碼不一致，請重新輸入。 The password you enter and re-enter did not match please try again .
182	vm-msginstruct.gsm	收聽下條留言，請按 6；重聽當前留言，請按 5；收聽前一條留言，請按 4；刪除或恢復刪除當前留言，請按 7；退出語音信箱，請按#號鍵；在收聽過程中，快速後退請按*號鍵；快速前進請按#號鍵 To hear the next message press “6”, to repeat this message press “5”, to hear the preview message press “4”, to delete or undelete this message press “7” ; to quit voicemail press pound .
183	vm-msgsaved.gsm	您的留言資訊已被保存。 Your message has been saved.

184	vm-newpassword.gsm	請輸入您的新密碼，以#號鍵結束。 Please enter your new password follow by the pound key.
185	vm-next.gsm	讀取下一條留言，請按 6 號鍵 Press “6” to playback next message.
186	vm-no.gsm	您已經沒有 No
187	vm-nobodyavail.gsm	抱歉，您撥打的客戶暫時無法接聽您的電話 Sorry, Nobody available take call the moment.
	Vm-nomessages.gsm	當前您郵箱中沒有留言 No messages.
188	vm-nomore.gsm	您已經沒有新的留言。 No more messages.
189	vm-Old.gsm	舊的 Old
190	vm-onefor.gsm	請按 1 號鍵 Press “1” for
191	vm-options.gsm	錄製無法接通提示音請按 1，錄製占線提示音請按 2，修改個人資訊請按 3，修改密碼請按 4，返回主菜單請按*號鍵。 Press “1” to record your unavailable message, press “2” to record your busy message, press “3” to record your name, press “4”to change your password , press “*”to return tho the main manu .
192	vm-opts.gsm	改變當前目錄請按 2，設置語音郵箱選項請按 0 Press “2” to change folder, press “0” for mailbox option.
193	vm-passchanged.gsm	密碼修改成功。 Your password has been changed.
194	vm-password.gsm	請輸入密碼 Password
195	vm-press.gsm	按 Press
196	vm-prev.gsm	收聽以往留言，請按 4 Press “4” to preview the message.
197	vm-rec-busy.gsm	現在開始錄製占線提示音。請在“嘀”聲後錄音，結束請按#號鍵。 After the tone say your busy message and then press pound key.
198	vm-rec-name.gsm	請在“嘀”聲後說出您的姓名，結束請按#號鍵。 After the tone say your name and then press ppound key.
199	vm-rec-unv.gsm	現在開始錄製無法接通提示音。請在“嘀”聲後錄音，結束請按#號鍵。 After the tone say your unavilable message and then press pound key.
200	vm-reenterpassword.gsm	請再次輸入您的密碼，以#號鍵結束。



		Please re-enter your password follow by the pound key.
--	--	--

No	File Name	Contents
201	vm-repeat.gsm	重播請按 5 Press “5” to repeat the current message.
202	vm-saved.gsm	已保存。 Saved.
203	vm-savedto.gsm	已保存到... Saved to...
204	vm-savemessage.gsm	或按 9 號鍵保存當前留言資訊。 Or 9 to save the message.
205	vm-sorry.gsm	抱歉，您的輸入有誤 Sorry, I’m did not understand your respond.
206	vm-savefolder.gsm	請選擇保存當前留言的目錄。 Which folder shuld I save message to .
207	vm-theperson.gsm	您撥打的客戶 The person at extension
208	vm-tocancel.gsm	或按#號鍵取消。 Or prompt to cancel .
209	vm-toforward.gsm	轉發該留言，請按 8 號鍵 Press “8” to forward the message to another user
210	vm-undelete.gsm	恢復刪除，請按 7 號鍵 Press “7” to undelete this message.
211	vm-undeleted.gsm	留言資訊被恢復。 Message undeleted
212	vm-whichbox.gsm	請輸入您的語音郵箱號碼。 To leave message please enter your mailbox number
213	vm-Work.gsm	工作 Work
214	vm-youhave.gsm	你有... You have .
215	vm-received.gsm	收到。 Received
216	vm-mailboxfull.gsm	很抱歉，該用戶語音信箱已滿，無法接收新的留言。 Sorry, the exist user mailbox can’t save more message.
217	vm-forwardoptions.gsm	需要處理後再轉發，請按 1；直接轉發，請按 2 。 Press “1” to prepend the message or “2” to forward the message without prepending .
218	vm-tocancelmsg.gsm	取消當前留言資訊，請按*號鍵 Press “*” the cancel this message.
219	vm-from.gsm	這是 from
220	vm-from-extension.gsm	這是分機號為

		Message from extension
--	--	------------------------

	File Name	Contents
221	vm-from-phonenumber.gsm	這是電話號碼為 Message from phonenumber
222	vm-unknown-caller.gsm	這是未知號碼的留言 From unknow caller.
223	vm-advopts.gsm	設置高級選項請按 3 Press “3” for advanced option.
224	vm-toreply.gsm	發送回復，請按 1 Press “1” to send reply.
225	vm-tocallback.gsm	回撥留言人號碼，請按 2 Press “2” to callback the person you save this message.
226	vm-tohearenv.gsm	收聽留言資訊頭，請按 3 Press “3” to hear the message handle.
227	vm-tomakecall.gsm	按 4 號鍵回撥 Press “4”
228	vm-starmain.gsm	返回主菜單，請按* Press “*” to return the main manu
229	vm-dialout.gsm	接通中，請稍候。 Please wait , I’ll make your call .
230	vm-enter-num-to-call.gsm	請輸入您想要撥打的電話號碼。 Please enter the number you will to call.
231	vm-then-pound.gsm	然後請按# Then press pound
232	vm-star-cancel.gsm	取消請按* Press “*” to cancel .
233	vm-num-i-have.gsm	您要撥打的號碼是 The number I have is
234	vm-tocallnum.gsm	撥打該號碼請按 1 Press “1” to call this number .
235	vm-calldiffnum.gsm	撥打其他號碼請按 2 Press “2” to enter your differen number
236	vm-nonumber.gsm	未知留言者。 I don't know who send the message.
237	vm-toenternumber.gsm	輸入新號碼請按 1 Press "1" to enter a number .
238	vm-nobox.gsm	您無法回復當前留言資訊，因為留言者沒有語音郵箱。 You can not reply this message, because sender have not mailbox .
239	vm-review.gsm	保存當前錄音請按 1，收聽當前錄音請按 2，重新錄製請按 3 Press “1” to exist to recording , press “2” to litten to it , press

		“3” to re-record the message.
240	vm-torecord.gsm	錄製留言請按 3 Press “3” to re-record the message.
241	vm-reachoper.gsm	需要總機幫助，請按 0 Press “0” to reach operator .
242	vm-leavemsg.gsm	發送語音郵件請按 5 號鍵 Press “5” to leave the message.