

FCC Certifications

This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.

CE Mark Warning

CE

This equipment complies with the requirements relating to electromagnetic compatibility, EN 55022 class B for ITE, the essential protection requirement of Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

Company has an on-going policy of upgrading its products and it may be possible that information in this document is not up-to-date. Please check with your local distributors for the latest information. No part of this document can be copied or reproduced in any form without written consent from the company.

Trademarks:

All trade names and trademarks are the properties of their respective companies.

Copyright © 2008, All Rights Reserved.

1. UN	PACKING INFORMATION
2. OV	ERVIEW
2.1	INTRODUCTION
2.2	KEY FEATURES
	LED DEFINITION
	P.3.1 10/100M
2	2.3.2 Link/Act
2	2.3.3 USB Link
3. INS	STALLATION
3.1	System Requirements
3.2	HARDWARE INSTALLATION
3	<i>B.2.1 Connect the adapter to your PC</i>
3	3.2.2 Networking cable installation
3.3	SOFTWARE INSTALLATION
3	3.3.1 Windows 2000 Setup
	3.3.2 Windows XP Setup
	3.3.3 Windows Vista Setup
	3.3.4 Mac OS Setup 1
	3.3.5 Wii Setup

1. Unpacking Information

Thank you for purchasing the USB-0202. Before you start, please verify that your package contains the following items:

- 1. One USB-0202.
- 2. One driver & manual CD
- *3.* QIG

2. Overview

2.1 Introduction

The USB-0202 provides users to launch Internet via the USB interface up to 100Mbps transferring and receiving rate.

The device is compatible to USB 2.0, 1.1, and 1.0. Along with complying 802.3, 802.3u and 802.3x standards, users are allowed to get connection to network in any environment that encountered. What's more, you would not have to endure the effort opening PC cases anymore.

To laptop users, it would be even more profitable with the low power consumption feature. Together with the high compatibility, laptop users are allowed to connect to network easily with lower power consumption and hence strengthen the power efficiency. Along with Plug & Play, hot inserting/swapping supported, the device makes your PC and peripherals being connected in much an easier way.

2.2 Key Features

- Complies with IEEE 802.3 10BASE-T standard
- Complies with IEEE 802.3u 100BASE-TX standard
- Complies with IEEE 802.3x full duplex flow control
- Compliant to USB 1.0, 1.1 and 2.0 standards
- Powered over USB bus with low power consumption
- Support full/half Duplex operation
- Support drivers for Windows 2000/XP/Vista
- Support drivers Mac OS 10.3, Mac 10.4 for 32-bit
- Active LED indicators
- Plug and Play Installation
- Support hot inserting and swapping
- Support Wake-on-LAN
- Support Wii player
- CE FCC, VCCI class B

2.3 LED Definition

2.3.1 10/100M

Green:	100M
Off:	10M

2.3.2 Link/Act

Green:	Valid link on this port
Blinking:	Data transmitting/ receiving
Off:	No valid link on the this port

2.3.3 USB Link

Green:	Valid link with this adapter
Off:	No valid link with this adapter

3. Installation

3.1 System Requirements

- A Pentium 166 MMX or above processor-based PC, any devices that support standard USB
- One available USB port
- Microsoft Windows 2000/XP/Vista/MAC OS 10.3 or 10.4 for 32-bit/64bit x86 and Power PC based computer.
- A CD-ROM Drive

3.2 Hardware Installation

Before installation, please check if there is an available USB port being enabled. To check this, you may click **My Computer** \rightarrow **Control Panel** \rightarrow **System**, then click the **Device Manager** tab to check if the **Universal Serial Bus controller** to be shown on the following list.

System Properties						
General Device Manager Hardware Profiles Performance						
General Device Manager Hardware Profiles Performance View devices by type View devices by connection Computer Disk drives Display adapters Floppy disk controllers Hard disk controllers Hard disk controllers Monitors Monitors Network adapters Ports (COM & LPT) System devices Iniversal serial bus controller UISB Root Hub USB Root Hub						
Properties Refresh Remove Print						
OK Cancel						

3.2.1 Connect the adapter to your PC

- 1. Plug the USB-0202 adapter to your PC.
- 2. Windows will detect new hardware automatically and prompt you for driver. For driver installation, please refer to the chapter "Software Installation".

3.2.2 Networking cable installation

- 1. Connect the UTP Ethernet cable to the network port of the USB Adapter.
- 2. Plug the other end of the cable into a 10/100 Switch or Hub.

Note: You may select the networking cable according to the following information:

10 BASE-T: Category 3, 4 or 5 UTP/STP 100 BASE-TX: Category 5 UTP/STP

3.3 Software Installation

After attaching the USB to Ethernet adapter to your PC or laptop, the auto-detection for new hardware will be activated automatically. The procedures to perform driver installation differ slightly from each operation system. Please refer to the following paragraphs for detail instruction.

3.3.1 Windows 2000 Setup

There are two ways to install the Win 2000 software: by using auto-install program, or, thorough the "Found New Hardware Wizard." Please refer to the following instruction.

Auto-Install Program

1. The "Found New Hardware Wizard" window pops up. Click "Cancel" to close the window.



2. Insert the CD-Rom that came with this product to your CD-Rom drive. Clickon **My Computer --> your CD-Rom drive --> Driver -→**

WinXP2K_32bit_driver Set up then double-click the icon to start installation.


3. After complete installation, click the "Finish" button.

3.3.2 Windows XP Setup

There are two ways to install the Win XP software: by using auto-install program, or, thorough the "Found New Hardware Wizard." Please refer to the following instruction.

Auto-Install Program

1. The "Found New Hardware Wizard" window pops up. Click "Cancel" to close the window.



- Insert the CD-Rom that came with this product to your CD-Rom drive. Click on My Computer --> your CD-Rom drive --> Driver -→ WinXP_2K_32bit_driver set up then double-click the icon to start installation.
- 3. After complete installation, click the "Finish" button.

3.3.3 Windows Vista Setup

There are two ways to install the Win Vista software: by using auto-install program, or, thorough the "Found New Hardware Wizard." Please refer to the following instruction.

Auto-Install Program

1. The "Found New Hardware Wizard" window pops up. Click "Cancel" to close the window.



- Insert LevelOne CD-Rom to your CD-Rom drive. Click on My Computer --> your CD-Rom drive --> Driver --→ Vista 32 bit press setup icon then it will start to install the driver
- 3. After complete installation, click the "Finish" button.


Found New Hardware Wizard


1. The "Found New Hardware" window pops up. Select "Locate and install driver software".



2. Select "I don't have the disc. Show me other options". Then, click "Next" to proceed.








3.3.4 Mac OS Setup

It is not necessary to install driver on Mac10.5 , it 's plug and play. Below are Mac 10.3 or 10.4 installation guideline


1. Insert the provided CD to your CD-Rom drive. Browse to Mac_OSX10.3 (or Mac_OSX10.4, which depends on your system). The install window pops up. Click "Continue."



2. Select a destination to install the driver on. Click "Continue" to proceed.

	Select a Destination
Introduction Select Destination Installation Type Install Finish Up	Select a destination volume to install the ASIX AX88772 v1.0.3 software. Mac 10.4.11 38.3GB (30.8GB Free) 38.3GB (36.1GB Free) 38.3GB (34.7GB Free) Tool 38.3GB (25.0GB Free) Install ng this software requires 483KB of space. You have chosen to install this software on the volume "Mac 10.3.9."

3. Click "Install" to start installation.



4. Product Specifications

Standard	IEEE802.3, 10BASE-T IEEE802.3u, 100BASE-TX IEEE802.3x full duplex flow control USB v 1.0 / 1. 1 / 2.0
Interface	1* USB port 1* 10/100Mbps Ethernet Port
Cable Connections	UTP Category 3,4,5,5e
Network Data Rate	100Mbps, 10Mbps
LED indications	1* 10/100M 1* Link/Act 1* USB Link
Input power	5V
Operating Temperature	$0^{\circ} \sim 40^{\circ}$ C (32° ~ 104°F)
Operating Humidity	10% - 90% non-condensing
Operation System	Windows 2000 / XP / Vista / MAC OS 10.3 / 10.4
Emission	CE, FCC, VCCI Class B