Figure 1-1

🖉 Enterprise Access Point - Windows Internet Explore 🔄 🕤 👻 🙋 http://192.168.1.1 File Edit View Favorites Tools Help 🥖 Enterprise Access Point

Figure 1-2



Figure 1-3









Figure 2-5



Note: The LevelOne Secure WLAN Controller series is powered by 4ipnet. LevelOne is partnered with 4ipnet to deliver most feature-rich product yet simple deployment in wireless networking infrastructure solution.

4ipnet is a leading provider of wireless networking solution software design house for manageable, reliable, and secure wireless access. In an effort to meet changing market demands at the least possible cost, 4ipnet delivers a diverse array of turnkey, high-performance products and mission-critical applications to bring reliability and manageability to increasingly complex wireless networks.



LevelOne

EAP series **Enterprise Access Point**

Quick Installation Guide

English Deutsch

Default Settings	
IP Address	192.168.1.1
Username	admin
Password	admin

V1.1

-





Figure 2-2



Figure 2-3



English

Web Management Interface Steps:

- 1. Enter the AP IP address "http://192.168.1.1" in the address field. (Figure 1-1)
- Enter the username "admin" and the password "admin". Click Login to log in. (Figure 1-2)
- 3. After a successful login into AP, a System Overview page of web management interface will appear. (Figure 1-3)

Change Administrator's Password:

 Click on the Utilities-> Change Password tab, enter the old password and then a new password in the *Password* field, and re-enter it again. Click *Save* to save the changes. (Figure 2-1)

Configure General AP settings:

1. Click on the Wireless-> General tab. Select your preferred Band and Channel for you wireless connection. (Figure 2-2) Configure VAP Profile settings:

1. Configure VAP profile settings :

(a) Select the **Wireless->VAP Config** tab to configure the settings of the desired VAP.

(b) Enable a specific VAP from the drop-down menu of Profile Name and configure related settings below. (Figure 2-3)

 After finishing VAP configuration, the status of enabled Virtual APs shall be reflected on the VAP Overview page. (Figure 2-4)

Configure WDS settings:

To extend the wireless coverage, it supports up to 4 WDS links for connecting wirelessly to other WDS APs. By default, all WDS profiles are disabled.

- A. Click on the Wireless main menu button.
- B. Select the Repeater Settings tab.
- C. Choose WDS as the Repeater Type.
- D. Choose the desired WDS profile:
 - Enable the WDS.
 - Enter the MAC Address (peer AP) and then Click SAVE.

If you use another EAP AP as the peer AP, simply repeat the above-mentioned steps to configure another peer AP(s).

Deutsch

Web Management Interface:

- Geben Sie die AP IP-Adresse "http://192.168.1.1" in das Adressfeld ein. (Bild 1-1)
- 2 Geben Sie den Username "admin" und das Passwort "admin" ein. Klicken Sie Login um fortzufahren. (Bild 1-2)
- Nach erfolgreicher Anmeldung des AP wird eine System-Übersichtsseite des Web-Management angezeigt. (Bild 1-3)

Änderung des Administrator Passwort:

 Klicken Sie auf Utilities -> Change Password, geben Sie das alte Passwort und dann ein neues Passwort in die Felder ein, wiederholen Sie das neue Passwort. Klicken Sie auf Save, um die Änderungen zu speichern. (Bild 2-1)

Konfiguration der generellen AP-Einstellungen:

 Klicken Sie auf Wireless -> General Tab. Wählen Sie das bevorzugte Band und den Kanal f
ür Ihre Wireless Verbindung. (Bild 2-2)

Konfiguration der VAP-Profil-Einstelungen:

- konfiguration der VAP-Profil-Einstellungen:
 (a) Wählen Sie Wireless -> VAP Config Tab zur Konfiguration der Einstellungen des gewünschten VAP.
 (b) Aktivieren Sie einen spezifischen VAP aus dem Auswahlmenü über den Profil-Namen und konfigurieren Sie dazugehörige folgende Einstellungen. (Bild 2-3)
- 2 Nach Abschluss der VAP-Konfiguration sollte der Status des aktivierten Virtuellen APs auf der VAP-Übersichtsseite sichtbar sein. (Bild 2-4)

Konfiguration der WDS-Einstellungen:

Zur Erweiterung der Funkabdeckung werden bis zu 4 WDS-Links zu anderen WDS-AP's unterstützt. Standardmässig sind alle WDS-Profile deaktiviert.

- A. Klicken Sie auf den Wireless main menu Button.
- B. Wählen Sie den Repeater Settings Tab.
- C. Wählen Sie WDS als den Repeater-Typ aus.
- D. Wählen Sie das gewünschte WDS-Profil:
 - Aktivieren Sie WDS.
 - Geben Sie die MAC-Adresse (Peer-AP) ein und klicken dann auf SAVE.

Sofern Sie einen anderen EAP-AP als Peer-AP nutzen, wiederholen Sie bitte die o.a. Schritte zur Konfiguration eines anderen Peer-APs.