



LevelOne
User Manual

GSW-0507 / GSW-0807
5/8-Port Gigabit Ethernet Switch

V1.0.0-0803

FCC Certifications

This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.

CE Marking Warning

This equipment complies with the requirements relating to electromagnetic compatibility, EN 55022 Class B for ITE, the essential protection requirement of Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

Company has an on-going policy of upgrading its products and it may be possible that information in this document is not up-to-date. Please check with your local distributors for the latest information. No part of this document can be copied or reproduced in any form without written consent from the company.



Introduction

The GSW-0507/GSW-0807 device are powerful, high-performance Gigabit Ethernet switch, with all ports capable of 10, 100 or 1000Mbps auto-negotiation operation (NWay), which means the switch could automatically negotiate with the connected partners on the network speed and duplex mode. It is ideal for micro-segmenting large networks into smaller, connected subnets for improved performance, enabling the bandwidth demanding multimedia and imaging applications. Moreover, the 10/100/1000Mbps auto-sensing ability provides an easy way to migrate 10/100Mbps to 1000Mbps network with no pain. Compared to the shared 10Mbps or 100Mbps networks, the switch delivers a dedicated 10/100/1000Mbps connection to every attached client with no bandwidth congestion issue. The GSW-0507/GSW-0807 switch also supports auto MDI / MDI-X function. Each port could be used to connect to another switch or hub with no crossover RJ-45 cable.

Store-and-forward switching mode promises the low latency plus eliminates all the network errors, including runt and CRC error packets. To work under full-duplex mode, transmission and reception of the frames can occur simultaneously without causing collisions as well as double the network bandwidth.

The switch is plug-and-play without any software to configure and also fully compliant with all kinds of network protocols.

Package Contents

- GSW-0507/GSW-0807
- Power Adapter
- User Manual
- Wall-Mounting Kit

If any of the above items are damaged or missing, please contact your dealer immediately.

Installation

The setup of the GSW-0507/GSW-0807 Switch can be performed using the following steps:

1. Install the Switch in a fairly cool and dry place. See Technical Specification for the acceptable operation temperature and humidity ranges.
2. Install the Switch in a site free from strong electromagnetic source, vibration, dust, and direct sunlight.
3. Leave at least 10cm of space at the left and right hand side of the Switch for ventilation.
4. Visually inspect the DC power jack and make sure that it is fully secured to the power adapter.

LED Definition

GSW-0507 Front Panel



GSW-0807 Front Panel




PWR	On	Power is on.
	Off	Power is off.
Link/Act (1~5/1~8)	On	One LED indicator will light green when a device is connected to the corresponding port.
	Blinking	The port is transmitting/receiving data.


Rear Panel

The rear panel of the GSW-0507/GSW-0807 switch consists of a DC power connector and 5/8 10/100/1000Mbps RJ45 Ports. The following figure shows the rear panel of the Switch.

• GSW-0507



• GSW-0807



Stations Connection

Connect each station to the switch by twisted-pair cable. Plug one RJ-45 connector into a RJ-45 port of the switch, and plug the other RJ-45 connector into the station's network adapter.

Power on the switch and then system is ready.

For cable selection, refer to the following table.

Switches Connection

In making a switch interconnection, you could use any port to connect another switch with straight or crossover cable. As all the ports support auto MDI / MDI-X function, using a straight cable to make a switch-to-switch connection is allowed.

For cable selection, refer to the following table :

Network Speed	Cable Type	Max. Length
10Mbps	Cat. 3, 4, 5 UTP/STP	100 meters
100Mbps	Cat. 5 UTP/STP	100 meters
1000Mbps	Cat. 5 UTP/STP	100 meters

Specification

Standard	<ul style="list-style-type: none">• IEEE 802.3 10BASE-T• IEEE 802.3u 100BASE-TX• IEEE 802.3ab 1000BASE-T• IEEE 802.3x Full Duplex Operation & Flow Control
Interface	<ul style="list-style-type: none">• 5/8 * 10/100/1000Mbps RJ-45 Gigabit Ethernet Ports (GSW-0507/GSW-0807)
NWay Protocol Support	<ul style="list-style-type: none">• 10Mbps: Full/Half duplex• 100Mbps: Full/Half duplex• 1000Mbps: Full duplex only
MAC Address Table	<ul style="list-style-type: none">• 1K MAC Address entries (GSW-0507)• 8K MAC Address entries (GSW-0807)
Buffer Memory	<ul style="list-style-type: none">• 832K bits (GSW-0507)• 144KBytes (GSW-0807)
Jumbo Frame	<ul style="list-style-type: none">• 12K Byte (GSW-0507)• 9K Bytes (GSW-0807)
Power Supply	<ul style="list-style-type: none">• 5VDC-1A, External (GSW-0507)• 12VDC-1A, External (GSW-0807)
Temperature	<ul style="list-style-type: none">• Operating Temperature: 0°C~40°C• Storage Temperature: -10°C~70°C
Humidity	<ul style="list-style-type: none">• Operating Humidity: 10%~90% non-condensing• Storage humidity: 5%~95% non-condensing
EMI	<ul style="list-style-type: none">• CE and FCC class A

Technical Support

Thank you for selecting LevelOne products. LevelOne's website contains the latest user documentation and software updates for LevelOne products.

Please contact LevelOne Technical Support through our website.

World Wide Web

<http://www.level1.com>